

## Dyness Battery System

# QUICK INSTALLATION GUIDE

Tower T Series-T7/T10/T14/T17/T21



## Target Group



### Skilled personnel recognized

This manual and the tasks and procedures described herein are intended for use by skilled workers only. A skilled worker is defined as a trained and qualified electrician or installer who has all of the following skills and experience:

- Knowledge of the functional principles and operation of on-grid systems.
- Knowledge of the dangers and risks associated with installing and using electrical devices and acceptable mitigation methods.
- Knowledge of the installation of electrical devices.
- Knowledge of and adherence to this manual and all safety precautions and best practices.
- Please note that this is the quick reference guide only. It is a shortened assistance for the installation of the Battery HV and does not replace the original installation manual. The original installation manual must be read and understood completely before installation. Please download and view the installation manual on this website: [www.eft-systems.de](http://www.eft-systems.de) (Downloads)
- In order to ensure the normal operation of Battery-Box, please be sure to update the firmware to the latest version and finish the configuration on Battery-Box webpage in accordance with this document.
- The system switch must be off before installing.
- Please make sure the system switch is off in case of the system not working, and it would be better to repair it again within one week, avoiding overdischarge or other problems happen.
- Please do not stack up batteries without protective package when storing or handling batteries, unless in the case of installation.

## Installation Environment Requirements

Max.  
+50°C

Min.  
-10°C

RH.  
+5%~+95%




YES



YES



YES



NO

Direct sunlight




NO

Direct rain fall




NO

Snow accumulation



NO

Flammable material or gas near the installation



NO

Flammable wall

## Tools



Wire Clamp



Phillips Screwdriver



Inclinometer




Wrench




Churn Drill

## Packing list

Item	Specification	Quantity	Figure
Communication Cable to Inverter	Standard, Black /L2000mm /RJ45 plug at both sides	1 PCS	
Communication Connector to BDU	RJ45 Waterproof connector	1 PCS	
M4 12pcs	M4*12	12PCS	
M6 3 Sets of Combined Screws	M6×2pcs	2 PCS	
OT terminal for Ground	OT4-6	2 PCS	
Power Cable Connector	To positive pole of battery	1 PCS	
Power Cable Connector	To negative pole of battery	1PCS	
Power Cable	Positive cable 6mm <sup>2</sup> ,red,2m	1 PCS	
Power Cable	Negative cable 6mm <sup>2</sup> ,black,2m	1PCS	


## Overall Structure

- Limited to the voltage interval of the inverter, the number of HV9637 modules used by the Tower series products is 2.
- Limited to the conversion conditions of the BDU internal DC, the maximum number of HV9637 modules in the Tower series of products is 6.



### 1 Unpack



BDU+Base




HV9637




### 2 Separate the BDU and Base



### 3 Balance





D1=50cm  
D2=30cm




### 4 Stacking and locking

**Note:** When assembling the BDU, ensure that the circuit breaker switch of the BDU is in the "OFF" state.





Tighten the fixed bolt in turn.

### 5 Connect the cable




**Note:** We recommend that a circuit breaker is installed between the battery and the inverter to prevent the battery or the inverter damaged when the short circuit occurs.

### 6 Earth connection



## 7 Battery system on


1. First, push the circuit breaker of BDU to the "ON" state.
2. Turn the self-locking switch to "ON", press and hold the "WAKE" button 3 ~ 7secs , release your fingers, the green light will always be on, and the battery will be turned on successfully.




Press and hold the "WAKE" button 3 ~ 7secs.

## 8 Parallel system

Dyness supports the maximum 12 cluster and machine use, it needs to configure a dedicated flow box. Single cluster installation is the same as it is used alone. For others, please consult Dyness.




9 KOSTAL PLENTICORE PLUS




Communication Cable Connection

10a Ingeteam (INGECON SUN STORAGE1 PLAY TL M)



Communication Cable Connection

10b Ingeteam (INGECON SUN STORAGE 100TL)




Communication Cable Connection

### 11 Goodwe ET Inverter

Dyness has a standard communication network cable. It is recommended to use the GW configuration network cable and directly connect to the CAN port of the battery BDU.


**Note:** PV Master selects the TOWER PRO version, to ensure that the inverter version is: x x x x 22.



4. CAN H  
5. CAN L


Tower T series

The 2 terminals are the Ethernet cable of the RJ45 terminal.



### 12 Solis RHI Series Hybrid Inverter


Use the configuration standard network cable.



4. CAN H  
5. CAN L

Tower T series



The 2 terminals are the Ethernet cable of the RJ45 terminal.



## TOWER System Expansion

### 13 Module expansion


It is necessary to ensure that the power of the added module is 100%, and the power of the expanded system is also 100%. (The dealer is required to provide SOC 100% module. If you operate by yourself, please follow the following steps.)



#### 13a Add the module to be charged between BDU and Base.



#### 13b Charge it with DC power supply until BDU is cut off, indicating that SOC is 100%.



**Note:** If you don't have equipment, please ask the dealer to fill up the capacity of the module you need to increase.



Power You Day and Night



Official Website



Digital version access

DYNESS RENEWABLE ENERGY GROUP CO., LTD.

[www.dyness-tech.com](http://www.dyness-tech.com)