


Debugging cables

1. Overall of all cables



2. RJ45 and RJ11 cables



3. USB-RS232 cables.




4. Connection between USB-RS232 and RJ11/RJ45




Please refer to the definition of DB9, they're female and male plug. Just make sure pin sequence of battery can match female plug.

Male to USB




Female plug to BAT 母头



Definition of RJ45 Port Pin

No.	CAN	RS485	RS232
1	---	---	---
2	GND	---	---
3	---	---	TX
4	CANH	---	---
5	CANL	---	---
6	---	---	RX
7	---	RS485A	---
8	---	RS485B	---



Change RJ11 to RJ45 cable (press a new RJ45 crystal head):

Green to Pin 3, white to Pin 6, Red to Pin 8 (GND)